

# PORTABLE LASER GONIOMETER



## USER MANUAL

**CATRA**

Henry Street, Sheffield S3 7EQ, UK

Telephone +44(0)114 276 9736

Facsimile +44(0)114 272 2151

E-mail [info@catra.org](mailto:info@catra.org)

Web <http://www.catra.org>

---

# **PORTABLE LASER GONIOMETER**

## **CONTENTS**

	<b>Page</b>
<b>1. Description</b>	<b>2</b>
1.1 Principal	
1.2 Laser	
<b>2. Safety</b>	<b>4</b>
2.1 Background	
2.2 Laser In User	
<b>3. Assembly and Operation</b>	<b>5</b>
3.1 Fixturing	
3.2 Setting-Up and Calibration	
3.3 Battery	
<b>4. Using the Device and Interpreting the Results on the Scale</b>	<b>7</b>

### **Appendices:**

#### **1 Laser Specification Sheet**



---


## 1. DESCRIPTION

This manual refers to the CATRA Portable laser edge angle measuring device, which is a small compact unit designed to be held in the hand.

### 1.1 PRINCIPLE

The design of the laser edge angle measuring device is based on the theory of light reflection

*; Angle of Incidence = Angle of Reflection*




*Fig 1.1*

A simple locating fixture is incorporated into the unit to locate the edge of the article in the path of a <1mm diameter laser light beam.

A circular scale of 90mm diameter is arranged around the article, where the point of incidence of the light beam on the component is in the center of the circle.

Depending upon how the scale is used, a virtual full 360° range is available, allowing measurements of the angle of incidence up to virtually the full 90°.

For a given angle of incidence  $\emptyset$  to the component, the scale reads physically  $2x\emptyset$ .



*Fig. 1.2*

The arrangement as shown enables the measurement of single or double sided beveled blades, which makes it particularly suitable for many kinds of cutting blades, using the correct method of fixturing.

---

---

## 1.2 LASER

The light source used is a low power visible red (wavelength 635 nm) laser diode incorporated in a compact housing which allows for safe and easy mounting. This unit is selected for its compact size and use with low power dc power supply it consists of a laser diode, lens and driver circuit housed in a metal case with electrical connections made by flying lead.

Laser Specification :

Type	Red Laser Diode
Wavelength	635 nm
Max. Output Power	1 mW
Operating Voltage	9 V dc
Beam Size	4.5 x 2.5 mm (unfocused) / 1 mm (focused)

By virtue of the front lens, a high quality collimated beam can be produced over a long distance. The lens position can be adjusted to focus the beam to a spot using the 'key' provided.

---

## 2. SAFETY

### 2.1 BACKGROUND

Laser devices produce beams of intense monochromatic light which can be potentially hazardous. The degree of hazard depends upon the wavelength of the light, the power or energy of the beam and the emission duration. The human eye is the most vulnerable organ as it will tend to focus the light from the beam onto the retina, thereby increasing the energy density level many times. If the irradiance of the device is high enough, skin damage can also result from exposure to the beam.

Laser safety is covered by BS (EN) 60825 which requires products to be classified according to their levels of radiation. This standard is essential reading for the users of lasers and also OEM manufacturers. The guidelines of this have been followed by CATRA in the selection of a laser and the design of the device.


### 2.2 LASER IN USE

The laser fitted into the measuring instrument as a low output device which omits visible infrared radiation at 635nm wavelengths

Power 0.9mW / wavelength 635nm

The body of the goniometer carries warning and information labels according to classification. In this application CATRA certifies the whole assembly of the device as

Class II	CDRH
Class 2	IEC 825



*Fig 2.1*

As further safety measures the unit has a momentary switch to enable the beam and a red indicator to show power and thus laser is on. Thus the beam need only be on for a short period of time to make a reading of the angles of a component.

Common sense dictates that the user should not stare directly into the beam or its reflections from highly mirrored surfaces. When the device is used in the correct manner for measuring sharpened angles then no harmful radiation is projected to the user. The operator normally only sees a fraction of the energy of the light when viewing the scale. Eye protection is normally afforded by the aversion responses, including the blink response.

---

DO NOT:

- a) View the reflections or the beam with optical aids such as telescopes or similar devices without taking additional precautions.
- b) Offer mirrored or highly reflective surfaces directly into the path of the beam in an "off-hand" manner as the direction of reflections will not be controlled.

DO:

- a) Place components into the properly designed fixtures which orientate the reflections onto the scale.
- b) Permit only suitable aware/responsible operators to use the device
- c) Use a pair of appropriate safety spectacles which filter out a certain percentage of the incident light in the visible infrared range when setting-up the unit or looking closely for abnormal reflections of non-standard applications.

### 3. LASER ASSEMBLY & OPERATION

The unit is supplied complete and ready assembled with the exception that the battery is not connected. A 9V PP3 battery is supplied and should be connected as per section 3.3.

#### 3.1 FIXTURING

A single multi-purpose magnetic fixture is fitted to the unit. This is specifically suited to single/double sided knife blades which should be presented with their cutting edge up to the datum pins as below.




Fig. 3.1

Fig. 3.1

---

For applications which are not suited to either arrangement the alternative fixturing may be developed.



---

### 3.2 SETTING-UP & CALIBRATION

The unit is set-up at CATRA's laboratories and several known, calibrated, ground edge standards are placed in the fixture to verify that the readings achieved are within tolerance.

The operate button is a momentary switch and thus the operator must hold a finger/thumb on this whilst ever an image is required.

### 3.3 BATTERY

To fit or change the battery, first remove the end cover by unscrewing the 2 screws. Find the standard PP3 press-stud type battery clip and connect with the correct polarity to the good battery. Slide the battery into its compartment with the connector facing outwards. Refit the end cover with foam packing where found.

The following diagram shows the goniometer and its main components:




Fig. 3.2

This unit is designed to operate on a standard / high powered PP3 9Vdc battery e.g. Duracell MN 1604. Alternatively a NiCad rechargeable may be used but this should be recharged outside the unit.

---

#### 4. USING THE LASER RIG AND INTERPRETING RESULTS ON SCALE

When set up properly and using the right fixturing, the goniometer is a means of obtaining a quick and reasonable accurate measurement of the angle of the bevelled edge/s of a component. One of the most frequent uses is the scanning of the ground edge on a knife blade by means of transversing the blade up and down with the point of beam incidence always at the datum, i.e. the centre of the scale, to measure the results obtained from the grinding process.

With the full  $360^\circ$  of scale available and the relatively wide beam it is possible to measure both sides of a double sided component being measured produces many different reflected patterns on the scale which can be interpreted as indicating the condition and/or shape of the reflective surface.

If the full circular beam were reflected from a flat true mirror surface then the reflection produced at the scale would be a circular dot Fig 4.1. Multiple faceted mirror surfaces would produce a reflection with a shape dependent upon the shape of the beam incident on it Figs 4.2, 4.3 & 4.4




Fig. 4.1




Fig.4.2




Fig.4.3

However, the above is not typical of the majority of actual blade type components manufactured. In practice, components produced by grinding and/or polishing processes do not behave as perfect mirrors and various other reflected patterns are observed due to the surface finish imparted by the process.

Of course, the closer the reflection is to the true dot then this is a measure of how near the surface is to a perfect mirror polish. The most common reflection pattern seen on the scale is a crescent shape (see figs. 4.4, 4.5 and 4.6) which is the result of reflections of points of light at compound angles, from the fine surface marks produced by the abrasive process, on an angled surface.

When the abrasive marks are normal to the edge of the blade (fig. 4.6a) and set in the plane of the beam, then the crescent is symmetrical about the horizontal plane, but if either the marks are angled or the blade edge is angled from the normal to the beam, then the crescent turns through an angle depending on which way the marks are leaning (Fig. 4.6b).

The true reading of the angle normal to a blade edge is achieved when the blade edge is normal to the beam and up to the datum (ie: centre of scale) and is read from the scale in the plane of the beam, ignoring the attitude of the crescent (eg: see figs. 4.5 and 4.6). All other readings not in the plane of the beam are the result of reflections at compound angles from the reflective surface/s.

The following illustrations show typical projections obtained from the common types of ground components whose cross-section in the plane of the beam (ie; the plane of the paper) at the point of incidence is drawn. These are drawn much simplified for clarity.




Fig.4.4




Fig 4.5




Fig 4.6

One of the advantages of the CATRA device is that both sides of a double edged component can be measured independently indicating the symmetry of the edge and also the total included angle if readings of both sides are summed.




Fig 4.7

Other features which are detected by their characteristic reflections are curved or hollow surfaces which produce a range of reflections as illustrated in Figs 4.3. A typical result on the scale would be such as shown in Figs 4.8 and 4.9 to where the reflections from a hollow ground blade span a small band of angles ranging between the two extremes of the curve.

Similarly, a convex radius on a component which has been polished to blend canal to the sides or a honed cutting edge, will produce a band of reflections over a range of angles. The former will exhibit a band between canal angle and side angle and the latter will have a band between the canal angle and virtually  $90^\circ$ .






Fig 4.8




Fig 4.9

These other features are generally less well defined than the predominant angled surfaces because less light is reflected from them and thus the reflections are of lesser intensity. Features with low amounts of reflected light are detected more easily by reducing the surrounding light level, total darkness being the optimum.

Other examples:-

- 1) Multi-cannelled edge with polishing and/or honing on tip such as a razor blade




Fig 4.10

---

## Appendix I

### Technical Specification


	635 nm
Beam output	Ellipical
Output power	0.9
Power stability (%)	<5
Wavelength (nm. @ 25°C)	635±5
Beam size (mm)	4 x 2
Minimum spot size (µm)	100
Beam divergence (mrad)	0.5
Pointing stability (mrad/°C)	<0.2
Bore sighting(°)	<2
Operating voltage (VDC)	3.0 – 10.0
Operating current (mA)	35
Operating temperature (°C)	-10 - +40
Storage temperature (°C)	-40 - +80
Material	HE30 Aluminium
Flying lead length	300 mm
Finish	Anodised


Typical values quoted unless otherwise stated.

Order Information			
	Out put	Product Number	Part Number
635 nm Laser diode module	0.9 mW	58 SDM 1	99 CLASER 0125

---

## LASER DIODE MODULE





**WIRING DIAGRAM**